ToxiRAE 3

Personal Gas Monitor for CO and H₂S



Lowest cost of ownership on the market

Rugged stainless steel housing for harsh environments

Fastest instrument response time on the market for better protection and worker safety

Fastest bump station on the market with highest productivity, putting workers back to work quickly

The ToxiRAE 3 is a full-featured single-gas monitor that offers unequaled cost of ownership value. The ToxiRAE 3 is compatible with the AutoRAE Lite bump and calibration station. The detector features a 2 year warranty and can record STEL, TWA, high, and low alarms.

Key Features

- High-performance, 3-electrode, pinless micro sensor with the fastest response time
- 0.1 ppm H₂S resolution, and high-range 1999 ppm CO available
- Large, easy-to-read display for gas concentration or days remaining (end-user adjustable)
- Event logging of up to 10 events
- Full activity records when used with AutoRAE Lite calibration station
- Intuitive, simple-to-operate user interface
- IP-67 water- and dust-resistant
- Loud, 95 dB audible alarm, bright red flashing visible LEDs, and internal vibration alarm
- Color-coded labels for gas type
- Extended operating temperature of -4° to 140° F (-20° to +60° C) with full T4 approval
- User-configurable bump/calibration reminders



Convenient small size



Bump testing ToxiRAE 3 with AutoRAE Lite Bump Test and **Calibration Station**











ToxiRAE 3

Specifications

Sensor Specifications*

Gas	Range (ppm)	Resolution (ppm)
H ₂ S	0 to 100	0.1
со	0 to 500	1
со	0 to 1999	1

Detector Specifications*

Size	3.4" x 2.2" x 0.8" (8.6 cm x 5.5 cm x 2.0 cm)	
Weight	3.5 oz (99.4 g)	
Battery	User-replaceable 2/3 AA high-capacity lithium	
Alarms	 95 dB typical (at 30 cm) buzzer and flashing red LED to indicate exceeded preset limits High: Displays "High" and emits 3 beeps and flashes per second Low: Displays "Low" and emits 2 beeps and flashes per second STEL: Displays "STEL" and emits 1 beep and flash per second TWA: Displays "TWA" and emits 1 beep and flash per second Vibration alarm 6-LED visible alarm 	
Data logging	10 events	
Response time	T90 < 12 seconds	
IP Rating	IP-67	
EMI/RFI	Highly resistant to EMI/RFI. Compliant with EMC directive 89/336/EEC	
Certification	US and Canada: C1D1, Groups A, B, C, D, T4 Europe: ATEX II 1G EEx ia IIC T4 IECEX: Ex ia IIC T4	
Operating Temperature	Continuous: -4° to 140° F (-20° to +60° C) Intermittent: -22° to 140° F (-30° to +60° C)	
Humidity	0 to 95% relative humidity (non-condensing)	
Warranty	2 years, including sensor and battery if used within specs	
Calibration	Two-point calibration for zero and span	

^{*}Specifications are subject to change

www.raesystems.com

RAE Systems Inc.

3775 North First Street San Jose, CA 95134 USA raesales@raesystems.com USA/Canada 1-877-723-2878 Europe/Russia +45 8652 5155 Middle East/Australia +971 4 3639 427 China +86 10 58858788

Asia +852 2669 0828

ToxiRAE 3 Ordering Options

Pack of 1

ToxiRAE 3 with specified sensor:

- 2/3 AA lithium battery
- One mini-CD with instruction manual and training materials
- Alligator clip
- Calibration adapter

Pack of 10

- 10 ToxiRAE 3 monitors with specified sensor
- 2 mini-CDs with instruction manual and training materials
- 2 calibration adapters
- 10 alligator clips

Pack of 100

10 packs of 10

Accessories (optional)

- Slide-in belt clip
- AutoRAE Lite



Ordering Information

Part Numbers

ToxiRAE 3 Monitor

Monitor	Pack of 1	Pack of 10	Pack of 100
H ₂ S	G01-0102-000	G01-0102-010	G01-0102-100
CO Low range	G01-0101-000	G01-0101-010	G01-0101-100
CO High range	G01-0103-000	G01-0103-010	G01-0103-100

AutoRAE Lite

Bump Test and Calibration Station	T01-0100-000

Toll-Free: 877-723-2878

